



How to Make a Crystal Wrapped Cuff Bracelet



We look forward to bringing you exclusive innovations
and distinctive products this year and beyond.

www.nunndesign.com

How to Make a Crystal Wrapped Cuff Bracelet

Designer: Becky Nunn

SUPPLIES NEEDED FROM KIT:

- 1 Hammered Cuff Bracelet
- 3' of 24-gauge gold wire
- 4.5" of Rhinestone Chain 14pp

TOOLS NEEDED:

- 1 pair Shear Flush Cutters
- 1 pair Needle Nose Pliers



NOTE:

Kit includes supplies for 3 Cuff Bracelets. This tutorial is written for assembling one cuff bracelet.



STEP 1: (Image 2)

Use needle nose pliers to create a 90-degree bend on the end of a piece of 24 gauge gold wire. Place the wire down onto the backside of the Hammered Cuff Bracelet $\frac{3}{4}$ " from the end of the cuff. Wrap the wire around the cuff 3 times, wrapping over the starting point to secure the wire to the cuff. Use a pair of needle nose pliers to tug firmly on the wire making the starting point very tight and secure. Trim away the excess wire of your starting point using a pair of flush cutters. Continue to wrap the wire around the cuff another time.

STEP 2: (Image 3)

Lay the strand of rhinestone chain onto the cuff bracelet with one end right next to your starting point. Keeping the chain in position while you wire wrap two times within the first gap of the rhinestone chain. This part can be a wee bit tricky, so be patient if it feels awkward to get started.

STEP 3: (Images 4-5)

Continue onto the next gap in the rhinestone chain and wire wrap 2 times again. Continue on until you are $\frac{3}{4}$ " from the other end of the cuff bracelet.

STEP 4: (Images 6-7)

Once you have arrived $\frac{3}{4}$ " from the end, wire wrap two times in between the gap of the rhinestone chain. Use your flush cutters to remove any excess rhinestone chain.

How to Make a Crystal Wrapped Cuff Bracelet

Designer: Becky Nunn

STEP 5: (Image 8)

Wrap your wire around the last link of the rhinestone chain another two times. Turn your cuff bracelet over and tuck your wire on the backside underneath your final wrapped area. Using needle nose pliers, pull firmly on the wire that is tucked under the wrapped area making it tight and secure. Trim the excess wire with flush cutters.

STEP 6: (Image 9)

Repeat the steps to make the other 2 cuff bracelets.



We have a lot to offer and would love for you to stay connected!

- Take a moment to cruise through our blog! --> www.nunndesign.com/blog
- Follow Nunn Design on Pinterest! --> www.pinterest.com/nunndesign
- Please Like us on Facebook. --> www.facebook.com/nunndesign