



How to Instructions Ornate Flat Tag Drop Earrings



We look forward to bringing you exclusive innovations  
and distinctive products this year and beyond.

[www.nunndesign.com](http://www.nunndesign.com)

**NUNN DESIGN SUPPLIES:**

- 2 Ornate Flat Tag Drop - Antique Silver (oftd-sb)
- 2 Jump Ring 6mm Textured Circle - Antique Silver (jr6tc-sb)
- 2 Jump Ring Grande Rope Circle - Antique Silver (jrgr-sb)
- 2 Ear Wires - Antique Silver (ews-b)
- Crystal Clay-Black (cryclay-black)
- Chaton Turquoise (cha-tur)

**TOOLS NEEDED:**

- Beeswax Toothpick or Magic Pick Lite
- 2 pairs of needle nose pliers
- Wet wipes
- Headpin



### TO ASSEMBLE THE PENDANTS

**STEP 1:** (Image 1)

Pinch off two equal lentil-sized balls, one of Part A (the color) and another of Part B (the hardener). Knead the two equal-sized balls fully together until the clay is a consistent color and not marbled.

**STEP 2:** (Images 2 & 3)

Split the mixed clay in half and roll one half into a ball and press it into the base of Nunn Design Ornate Flat Tag Drop. Pat the clay gently until it is slightly domed and fully flushed to the edges. Repeat with the other half of clay and the second Ornate Flat Tag Drop.

**STEP 3:** (Images 4 & 5)

Using a beeswax toothpick, Magic Pick Lite or Jewel Setter, pick-up the individual Turquoise Chatons and gently press each into the Epoxy Clay. Continue to press Chatons in until complete. You have approximately 2 hours to work with the Epoxy Clay, so take your time and enjoy. Repeat with the second Ornate Flat Tag Drop.

**STEP 4:** (Images 6-8)

If you have a gap within your Chatons and have more clay showing through than you would like, pinch off a small ball of clay and press it gently into the gap with a headpin. Press in a Chaton into the built up area and clear away the excess Epoxy Clay. Repeat for the second Ornate Flat Tag Drop.

**STEP 5:** (no Image)

Use your fingers to gently press the Chatons into the clay, making sure that all of the Chaton points are secure and embedded fully into the clay. You can also use your fingers to gently sculpt the Chatons/Epoxy Clay to be evenly domed. The Epoxy Clay will harden within 2 hours and fully cure within 24. Repeat for the second Ornate Flat Tag Drop.

### TO ASSEMBLE EARRINGS

**STEP 6:** (Images 9-12)

Using two pairs of needle nose pliers, open the 6mm Textured Jump Ring. Thread through the Ornate Flat Tag Drop and the Jump Ring Grande Rope Circle. Close jump ring. Repeat for the second earring.

**STEP 7:** (Images 13 & 14)

Open the loop on one ear wire and attach the jump ring grande rope circle, and close the ear wire. Repeat for the second earring.

**Pull that hair up into a bun and enjoy the compliments of your newest creation!**