

HOW TO USE ORGANICS IN OPEN BACK BEZELS WITH NUNN DESIGN 2-PART RESIN



1

Prepare your Organics (by air-drying, using Silica Gel, Spray Resin or a coat of resin).



2

Place bezel on packing tape, apply pressure to burnish bezel down, trim excess tape. Use toothpick to press organics onto tape.



3

Pour equal parts of A, then B, of Nunn Design 2-Part Resin into cup, mix for 2 minutes and put under lamp for 5 min.



4

Slowly drizzle the mixed resin over the organics filling the bezel partially (1/2 - 2/3 full). Do not fill bezel completely.



5

Use a toothpick to agitate the resin and make sure there aren't any air bubbles.



6

Let your resin cure. See how this cured piece has the organics sticking above the resin. (It can float up while curing)



7

Mix up another batch of 2-part resin and drizzle into your bezel. Use a toothpick to make sure there aren't bubbles lurking!



8

Let cure. Remove tape. Use tape to remove any excess residue. Viola!