



---

# NUNN DESIGN®

---

How to Instructions For Epoxy Clay Button Ponytail Holders



We look forward to bringing you exclusive innovations  
and distinctive products this year and beyond.

[www.nunndesign.com](http://www.nunndesign.com)

**NUNN DESIGN SUPPLIES:**

Crystal Clay Brown (cryclay-brown)  
 Rhinestone Chain 24pp - Antique Gold (rc24-gb)  
 Ponytail Holder - Antique Gold (pth-gb)

**OTHER SUPPLIES:**

Vintage buttons  
 Black Elastic Ponytail Holder

**TOOLS NEEDED:**

Headpin



**TO ASSEMBLE THE PONYTAIL HOLDER**

**STEP 1:** (Image 1)

Using Crystal Clay, follow the manufacturers instructions for safety. Pinch off two equal balls of Part A (the color) and Part B (the hardener). (You will want your combined Crystal Clay ball to be approximately ½ size of the vintage buttons you will be using).

**STEP 2:** (Image 2 & 3)

Knead the two equal size balls fully together until the clay is a consistent color and not marbled. You have 60-90 minutes to work with the clay before it starts to harden. **INSET:** Put aside a small ball of kneaded clay to attach the ponytail holder finding in Step 6.

**STEP 3:** (Image 4)

Roll a large ball of kneaded clay and press into the base of one of the sides of the vintage buttons.

## How to Instructions For Epoxy Clay Button Ponytail Holders

**STEP 4:** (Image 5)

Put the kneaded clay between the two vintage buttons and sandwich together (like an Oreo cookie). Press firmly, squeezing the clay out to the edges.

**STEP 5:** (Image 6)

Press the rhinestone chain into the Crystal Clay, wrapping it around the sandwiched edges of the buttons.

**STEP 6:** (Image 7 & 8)

To attach the ponytail holder, roll out two small balls of the Crystal Clay (set aside from Step 2). Attach each ball to the bottom platforms of the ponytail finding. With the black elastic ponytail holder in place, press the ponytail finding to the base of one of the vintage buttons. If any Crystal Clay squeezes out the sides, use a headpin to scrap away the excess.

**STEP 7:** (no image)

Allow this piece to cure 12-24 hours before wearing.

